



Portable CD Player with cassette deck and FM radio

The portable boombox from SCHWAIGER[®] combines a CD player, a cassette player and a FM radio in one and provides a wide range of playback options: Play your favourite CDs, inspire your children with classic radio play cassettes or connect your modern playback

devices via AUX and USB. And you're able almost everywhere you are. Because you can easily connect the Boombox at home via the power cord or take it with you wherever you go with the comfortable carrying handle.



ARTICLE INFORMATION

Article Nr 661668
EAN 4004005661668



Last updated: 04.01.2022



FEATURES (661668)

- boombox with top-loading CD player, cassette deck and FM radio reception
- CD / CD-R / CD-RW / MP3 disc compatible
- with USB connection for playback of MP3 and WMA files
- sonorous sound with 2x 1.2 W RMS output
- 30 program memory locations for radio stations
- up to 4 hours of listening pleasure on battery power
- can be used both with power cord and mobile battery operated
- easy to control via device keys
- automatic channel scan
- headphone output
- telescopic rod antenna for best-possible alignment
- radio reception via FM (analog)
- contents: Boombox, power cable, operating instructions

TECHNICAL DATA

Connections	1x IEC socket (IEC 60320 C7) 1x USB 2.0 A jack 2x 3.5 mm jack plug socket (stereo)
Reception frequency	87,5 - 108 MHz (FM)
Power supply	via power cord 230 V AC , 50 Hz via battery: 9 VDC
Batteries	6x C (Baby)
Battery service life (max.)	4 h
Power consumption	16 W (in operation) < 1 W (in stand-by)
Display	LCD display

Power rating	2x 1,2 W (RMS, loudspeaker)
Programme memory slots	30 (FM)
Colour	pink/white
Dimensions (width)	260 mm
Dimensions (height)	133 mm
Dimensions (depth)	232 mm
Weight (set)	1700 g
Model number	BBP24
Packaging	carton