



## devolo Home Control Wassermelder

More security with the Home Control Floodsensor

The devolo Home Control Floodsensor is a compact, battery-operated sensor which can be easily positioned in a matter of seconds. The sensor reliably monitors your dishwasher, washing machine or other household appliances for impending leaks. As soon as a leak

or flood is detected, the sensor sends you a message via your preferred method. The flood-sensor also detects storm-related floods and provides timely notification about impending water damage.



### ARTICLE INFORMATION

Article Nr  
EAN

DEV9670  
4250059696709



Last updated: 25.04.2017



## FEATURES (DEV9670)

- Reliably provides warnings of looming water damage in the case of defective washing machines, dishwashers, overflowing baths and in the case of floods.
- Sends notifications via text message, e-mail and app (push notifications).
- Rugged and compact for unobtrusive positioning throughout the home.
- Versatile installation via adhesive film or screws (both in the scope of delivery).
- Long range and long battery life (up to 5 years).
- Intuitive operation via web browser or free app for smartphones and tablets.
- Can be combined at any time with other devolo Home Control components.
- Future-proof thanks to standardised Z-Wave® wireless technology.
- content: devolo Home Control Floodsensor with battery, mounting accessories, installation manual

## TECHNICAL DATA

Integrated protocols	Z-Wave
Frequency range	868,42 MHz
Range	up to 25 m indoor up to 100 m outdoor
Point of use	indoor use
Operating temperature	-10° - 40 °C
Ambient conditions	0 - 85 % humidity (non-condensing)
Display	LED
Button	1
Battery type	CR123A

Operating systems	from Windows® 7/Linux® (Ubuntu)/Mac OS® X
Certifications	CE Class B (EU, CH, NO)
Cable length	1.5 m
Dimensions (width)	28 mm
Dimensions (height)	85 mm
Dimensions (depth)	23 mm
Guarantee	3 years manufacturer's guarantee
Packaging	carton