



Glass Breakage Alarm

with magnetic contacts

This SCHWAIGER® glass breakage alarm is used to secure windows, glass doors and sliding doors. As soon as the window or door is opened by an unauthorized person or the glass pane breaks (e.g. due to intentional breakage or a storm), an alarm sounds in

order to discourage intruders. For this reason, this product is perfect for securing any vulnerable point of entry.



ARTICLE INFORMATION

Article Nr
EAN

HSA250 532
4004005018592



Last updated: 06.04.2017



(HSA250 532)

- alarm is triggered by vibration or breakage of the glass
- alarm is triggered by separating the magnetic contacts
- loud deterrent alarm signal
- for securing windows, glass doors or sliding doors
- directly discourages intruders
- attracts attention of passers-by or people in the nearby area
- alarm is activated and deactivated with a controller
- batteries can be exchanged without having to demount the device
- very easy installation
- fixing by adhesive pad
- key for testing the battery function
- battery-operated (batteries included)
- content: alarm unit, magnetic contact, mounting material, 2x button cell battery (CR2032)

TECHNICAL DATA

Point of use	indoor use
Mounting type	with adhesive pad
Volume	alarm signal 95 dB
Batteries	2x CR 2032
Power supply	via batteries
Material of product	plastic

Colour	white
Dimensions (width)	75 mm
Dimensions (height)	7 mm
Dimensions (depth)	75 mm
Packaging	sealed blister SF

Last updated: 06.04.2017