



## Home Alarm

with motion detector and keypad

This SCHWAIGER® home alarm is used to secure property and houses. As soon as the motion detector detects a violation, an alarm is triggered in order to discourage intruders. For this reason, this product is perfect for securing any vulnerable point of entry. Due to

the integrated delay function, authorised people can enter the property / building without triggering an alarm.



### ARTICLE INFORMATION

Article Nr  
EAN

HSA600 532  
4004005019230



Last updated: 06.04.2017



(HSA600 532)

- alarm is triggered upon detection of motion
- two different modes selectable - can be used as doorbell or alarm unit
- loud deterrent alarm signal
- for securing hallways or entrance areas
- built-in PIR sensor makes for reliable detection of motion
- large coverage area
- alarm is activated and deactivated by entering a 4-digit PIN code
- PIN code can be customised
- delay function
- integrated status LED
- battery-operated (batteries not included)
- content: motion detector, wall mount, mounting material

## TECHNICAL DATA

Point of use	indoor use
Mounting type	with screws
Volume	alarm signal 120 dB
Coverage angle (PIR)	110 °
Batteries	3x LR03 (AAA)
Power supply	via batteries

Material of product	plastic
Colour	white
Dimensions (width)	70 mm
Dimensions (height)	25 mm
Dimensions (depth)	125 mm
Packaging	sealed blister SF

Last updated: 06.04.2017