



Ceiling Alarm

with motion detector and remote control

This SCHWAIGER® home alarm is used to secure property and houses. As soon as the motion detector detects a violation, an alarm is triggered in order to discourage intruders. For this reason, this product is perfect for securing any vulnerable point of entry. Due to

the integrated delay function, authorised people can enter the property / building without triggering an alarm. The alarm is activated and deactivated via remote control.



SECURE 4 YOU


ARTICLE INFORMATION

Article Nr
EAN

HSA700 532
4004005019247



Last updated: 27.03.2017



(HSA700 532)

- alarm is triggered upon detection of motion
- two different modes selectable - can be used as doorbell or alarm unit
- loud deterrent alarm signal
- for securing hallways or entrance areas
- built-in PIR sensor makes for reliable detection of motion
- large coverage area
- alarm is activated / deactivated via remote control
- delay function
- integrated status LED
- battery-operated
- size of remote control (WxHxD): 30 x 6 x 60 mm
- content: motion detector, ceiling mount, remote control with battery (CR 2032), mounting material, user manual

TECHNICAL DATA

Point of use	indoor use
Mounting type	with screws
Batteries	alarm: 3x LR06 (AA) remote control: 1x CR 2032
Volume	alarm signal 110 dB
Coverage angle (PIR)	110 °
Coverage area	360 °

Power supply	via batteries
Material of product	plastic
Colour	white
Dimensions (width)	125 mm
Dimensions (height)	45 mm
Dimensions (depth)	255 mm
Packaging	sealed blister SF

Last updated: 27.03.2017