



Panic Alarm

for the key ring

This SCHWAIGER® panic alarm is a personal security gadget. In dangerous situations, it can be used to deter possible attackers by triggering the alarm, a loud signal tone. Due to its small size, this product is the perfect companion in any situation. The panic alarm

can for example be added to a key ring or fastened on a handbag.



ARTICLE INFORMATION

Article Nr
EAN

HSP100 533
4004005018547



Last updated: 27.03.2017



(HSP100 533)

- alarm is triggered by simultaneously pressing the two keys which are located on the sides
- loud deterrent alarm signal
- directly deters attackers
- attracts attention of passers-by or people in the nearby area
- built-in LED lamp with flashlight function
- additional fastening clamp
- compact size, perfect to keep in handbag
- extremely long battery life
- content: panic alarm, 3x button cell battery (LR44)

TECHNICAL DATA

Battery type	LR44
Volume	alarm signal 110 dB
Power supply	via battery: 3 pieces
Material of product	plastic
Colour	black

Dimensions (width)	40 mm
Dimensions (height)	15 mm
Dimensions (depth)	75 mm
Packaging	clamshell SF

Last updated: 27.03.2017