



Panic Alarm

for the key ring

This SCHWAIGER® panic alarm is a personal security gadget. In dangerous situations, it can be used to deter possible attackers by triggering the alarm, a loud signal tone. Due to its small size, this product is the perfect companion in any situation. The panic alarm

can for example be added to a key ring or fastened on a handbag.



SECURE 4 YOU

ARTICLE INFORMATION

Article Nr
EAN

HSP200 533
4004005018554



4 004005 018554

Last updated: 27.03.2017



(HSP200 533)

- alarm is triggered by removing the contact pin
- two sirens make for an even louder alarm signal
- attracts attention of passers-by or people in the nearby area
- compact design, perfect for on the go
- extremely long battery life
- battery-operated (batteries included)
- content: panic alarm with 4 button cell batteries (LR41), user manual

TECHNICAL DATA

Batteries	4x LR41
Volume	alarm signal 120 dB
Power supply	via batteries
Material of product	plastic
Colour	black

Dimensions (width)	20 mm
Dimensions (height)	10 mm
Dimensions (depth)	75 mm
Packaging	sealed blister SF

Last updated: 27.03.2017