



SOS Emergency Alarm

This SCHWAIGER® SOS emergency alarm is a personal security gadget. It is portable and can be used on the go but also comes with a wall mount. In dangerous situations, it can serve to deter possible attackers by triggering the alarm, a loud signal tone. Due to the fact

that the alarm tone also attracts the attention of people nearby, the SOS emergency alarm is also perfect for older people to carry around at home.



ARTICLE INFORMATION

Article Nr
EAN

HSP300 531
4004005018561



4 004005 018561

Last updated: 06.04.2017



(HSP300 531)

- alarm is triggered by removing the contact pin
- loud deterrent alarm signal
- directly deters attackers
- attracts attention of passers-by or people in the nearby area
- can be mounted on a wall or be used on the go
- ON/OFF switch
- key for testing the battery function
- integrated status LED
- extremely long battery life
- battery-operated (batteries not included)
- content: emergency alarm, wall mount, mounting material

TECHNICAL DATA

Point of use	indoor use
Mounting type	with adhesive pad/screws
Volume	alarm signal 120 dB
Batteries	2x LR03 (AAA)
Power supply	via batteries
Material of product	plastic

Colour	red
Dimensions (width)	80 mm
Dimensions (height)	20 mm
Dimensions (depth)	85 mm
Packaging	sealed blister SF

Last updated: 06.04.2017